

MyBinding MY2700 Roll Laminator

Call Us
at 800-451-7329



Provided By

MyBinding.com®
When Image Matters.

OPERATING INSTRUCTIONS

TSL- 2700

1 IMPORTANT SAFEGUARDS

When using electrical appliances, basic precautions should always be followed to reduce the risk of electric shock and injury to people, including the following:

1. Read all instructions.
2. Always unplug the appliance when not in use or before cleaning.
3. Do not use outdoors.
4. Extreme caution should be taken when the appliance is used by or near children or invalids.
5. To protect against risk of electrical hazards, do not immerse cord, plugs, or appliances in water or other liquids.
6. Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions has been dropped or is damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. Do not use accessory attachments not recommended or sold by the appliance manufacture.
8. Do not let cord hang over edge of counter, or touch hot surfaces.
9. Do not use the appliance for other than intended use. This appliance is intended for Office or Household use only.
10. The socket outlet shall be installed near the equipment and shall be easily accessible.
11. Warning-hazardous involving parts-keep fingers and other body parts away.
12. To minimize bubble in the finished product, do not push the material into the laminate instead slowly slide the material toward the laminate until it gets in contact with the roller and is fed. Into the laminate automatically.
13. **Not to lift the machine by holding on to the end caps otherwise they will break**

2. LOCATION

Please remove the laminator carefully from packaging, place the machine on a flat work surface. Place the machine in an area where it will normally be used ensuring adequate room for the finished laminate to flow or slide out at the back.

3 HOW TO USE

(1) TWO SIDE LAMINATION

LOADING THE FILM

Unpack the upper and lower rods. Remove feed tray. Slide the roll film onto the rods, leaving equal lengths of rod out of each end. Use the guide marks to position the roll of film. Load the rods on the laminator.

Note: you cannot interchange the upper and lower rods.

THREAD THE FILM

Read the threading card supplied with each TCC roll of film carefully. Please see the threading card. Do not mistake the re-enforcing bar for idler roller. To thread the film through the "hot" rolls & pull rolls, please pull the handle forward to release pressure on all the rollers. Push the film through the rollers and make sure the film is perfectly aligned at the top and bottom (Note: overlap will cause the film to deposit residue on the hot roll and pull rolls, so this procedure is critical) .

HEAT ADJUSTMENT TSL-2700

1. After turning on the power switch. Please press the **1** key to start the heat process while the heater light will glow for 1.5 mil. roll-film laminating use .
2. The ready light will glow when it reaches the temperature you set, while you can start to laminating.
3. Please press the **2** key for 3 mil. roll-film laminating .

(2) ONE SIDE MOUNTING

LOADING THE FILM

Unpack the upper rods, Slide the adapter by film--- adapter---film onto the rods and fit the adapter onto the paper core. Leave equal lengths of the rod out of each end. Use the guide to position the roll of film then tighten the screw on the adapter to secure the roll film. Load the rods on the laminator.

THREAD THE FILM

Read the threading card supplied with each TCC roll of film carefully. Do not mistake the reinforcing bar for idler roller. Please pull the handle forward to release pressure on all the rollers, then thread the film through the upper hot rolls & pull rolls. Push the film through the rollers and make sure the film is perfectly aligned.

ADJUST THE TWO ROLLER GAP

1. Push the handle on the right side of the machine forward to match the signal 3/16" or 1/2" for the same size mounting

HEAT ADJUSTMENT TSL-2700

1. After turning on the power switch. Please press the **1** key to start the heat process while the heater light will glow for 1.5 mil. roll-film mounting use .
2. The ready light will glow when it reaches the temperature you set, while you can start to mount.
3. Please press the **2** key for 3 mil. roll-film mounting .

We Have it All...



MyBinding.com *When Image Matters.*

Guaranteed Lowest Prices on an
Endless Selection of Binding Systems, Laminators,
Paper Shredders, Supplies and Accessories.

We have you covered with Expert Advice
and Support. Our popular blog keeps you up to
date on the latest tips and techniques to make
your most important binding and laminating
tasks a success.

Call Us Today

1-800-944-4573

Our Trusted Partners

GBC / Ibico
Fellowes
Powis Fastback
Unibind
Akiles
Renz
Tamerica
Rhin-O-Tuff
DFG

Pro-Bind
Martin Yale
MBM
Formax
Intimus
Dahle
HSM
Standard
Xyron

Challenge
Lasko-Wizer
GBC Shredmaster
Avery
Wilson Jones
Cardinal
Samsill
Universal

BINDING MACHINES
BINDING SUPPLIES
LAMINATORS
I.D. ACCESSORIES
BOARDS & EASELS
PAPER SHREDDERS
XYRON LAMINATORS
COIL BINDING MACHINES
UNIBIND BINDING MACHINES
FASTBACK BINDING EQUIPMENT
PAPER FOLDING MACHINES
LAMINATING POUCHES
ROTARY TRIMMERS
CLEAR COVERS
TWIN LOOP WIRE
REGENCY COVERS
PLASTIC BINDING COVERS
VELOBIND BINDING MACHINES
PAPER HANDLING EQUIPMENT
THERMAL BINDING MACHINES
PROCLICK BINDING SYSTEMS
COMB BINDING MACHINES
COMB BINDING SUPPLIES
WIRE BINDING MACHINES
POUCH LAMINATORS
LAMINATING ROLLS
3-RING BINDERS
ROLL LAMINATORS
VELOBIND SPINES
PAPER CUTTERS
PAPER JOGGERS
LETTER OPENERS
THERMAL COVERS
UNIBIND SUPPLIES
PROCLICK SPINES
ZIPBIND SPINES
LINEN COVERS
SPIRAL COIL
INDEX TABS